A Guide To Spacing Spotlights

Under Cabinet Lights

When it comes to under cabinet lighting it's important to consider a few different factors, the first being corners. Corners of worktops can become extremely dark and unusable when lighting is not planned correctly. If your spacing does not consider the corners you will not be able to make the most of this all important surface space. Plan your lighting starting from the corners and work inwards to avoid this problem.

Another important aspect of planning under cabinet spotlights is to space the lights with even and consistent distances between each fitting. As a general rule of thumb it is good practice to have a spotlight every 500mm to ensure a great spread of light. If there is not enough distance between each light then the effect will become too concentrated. With VEW lighting cabinet spotlights, the lumen output will be effective enough with a wide and efficient beam angle, meaning there is no need to overcrowd your lights. It is also important to keep spotlights even to ensure an attractive symmetry in your kitchen. Uneven lights can look unpleasant, especially at darker times in the day.

For more information please contact sales@tlwglobal.com

TLW Intelligent Lighting Solutions